





! This document contains technology subject to the Export Administration Regulations (15 C.F.R. Parts 730-774). A prior authorization or license from the U.S. Department of Commerce, Bureau of Industry and Security (BIS) is required prior to the export, re-export, release, or transfer of this document to a non-U.S. person whether in the United States or abroad.

MAGAZINE CATCH SPRING INSTALLATION INSTRUCTIONS




STEP 1: UNINSTALL MAGAZINE RELEASE BUTTON

Using a delrin punch or other non-marring tool, depress the *magazine release button* in far enough that the *magazine catch* can spin freely. Spin the *magazine catch* until the *magazine release button* is free of the threaded post.



STEP 2: REPLACE MAGAZINE CATCH SPRING

Remove *magazine catch spring* and set aside. Retain the *magazine catch* and *magazine release button*. Push the *magazine catch* in as far as possible. Place the *enhanced magazine catch spring* over threaded portion of *magazine catch* and replace the *magazine release button*.



STEP 3: RE-INSTALL MAGAZINE RELEASE BUTTON

Using a delrin punch or other non-marring tool, depress the *magazine release button* in far enough that the *magazine catch* can spin freely. Spin the *magazine catch* until end of the threaded post is flush with the top of the *magazine release button*.

Perform final inspection including function check in accordance with firearm user manual to verify proper weapon function. Always test fire your weapon before using it in an operational environment.