





SLING MOUNT KIT




- ⚠ WARNING: BEFORE STARTING, MAKE SURE THE WEAPON IS UNLOADED, THE CHAMBER IS EMPTY, AND THE SAFETY ENGAGED.**
- ⚠ CAUTION: PLEASE READ ALL INSTRUCTIONS BEFORE PROCEEDING. COMPONENTS UNDER SPRING PRESSURE MAY EJECT FORCEFULLY AND COULD CAUSE INJURY.**
- ⚠ WARNING: OBSERVE SAFE FIREARM HANDLING PRACTICES AT ALL TIMES. FAILURE TO DO SO MAY RESULT IN SERIOUS BODILY INJURY OR DEATH. MAGPUL INDUSTRIES SHALL NOT BE RESPONSIBLE FOR INJURY, DEATH OR PROPERTY DAMAGE RESULTING FROM FAULTY INSTALLATION, MISUSE, ILLEGAL USE, OR MODIFICATION OF THIS PRODUCT.**

INSTALLATION INSTRUCTIONS

INSTALLATION SCHEMATIC




TYPE 1 INSTALLATION INSTRUCTIONS



For the SGA Stock, gently remove the QD Plugs from both sides with small flat-head screwdriver. To install on the SGA Stock or front mounting point on the MOE Rifle Stock, line up the Type 1 QD Cup (1) on the desired side of use and insert the 10-24 x 1/2" Button Head Screw (3) through the QD Cup (1). Align the Nut (2) on the opposite side of the stock. Thread and tighten the screw into the Nut (2) with a 1/8" hex key, taking care not to overtighten. To install on the rear mounting point on the MOE Rifle Stock, use the 10-24 x 1" Button Head Screw (4).

CAUTION: DO NOT OVERTIGHTEN. Overtightening may result in unwanted damage to the QD mount or to the stock body itself.


TYPE 2 INSTALLATION INSTRUCTIONS



Select the QD location to be made ambidextrous and loosen the 10-24 x 5/8" Button Head Screw. Remove the washer and/or nut opposite the existing QD cup and replace with the Type 2 QD Cup (1). Thread the original Button Head Screw into the QD Cup (1) and hand tighten using a 1/8" hex key, taking care not to overtighten.

CAUTION: DO NOT OVERTIGHTEN. Overtightening may result in unwanted damage to the QD mount or to the stock body itself.

TYPE 3 INSTALLATION INSTRUCTIONS



Align the Type 3 QD Mount (1) on the desired side of stock. Insert the provided 10-24 x 1" Button Head Screw (2) into the appropriate hole behind the release lever. Thread and tighten the 10-24 x 1" Button Head Screw (2) into the QD Mount (1) using a 1/8" hex key, taking care not to overtighten.

CAUTION: DO NOT OVERTIGHTEN. Overtightening may result in unwanted damage to the QD mount or to the stock body itself.